Type of Sewer Systems

Solomon Seyoum

earning objectives

- Upon completion of this lecture, the participants each type of sewer systems such as sewer systems and discuss different aspects of will be able to differentiate between types of
- Design aspects
- operation and maintenance aspects,
- Cost aspects and
- Applicability

ypes of sewer systems

- Principles of collection:
- Combined
- Separate
- Above ground/underground
- Principles of transport
- Gravity
- Pressure
- Vacuum

ypes of sewer systems

- Combined Sewers
- Separate Sewers
- Simplified Sewers
- Solid free sewers
- Pressurised sewers
- Vacuum sewers
- Open channel drains

Combined Sewers

- are large networks of underground pipes that centralised treatment facility convey domestic sewage, industrial wastewater and stormwater runoff in the same pipe to a
- mostly found in urban areas
- do not require on-site pre-treatment or storage of the wastewater
- Transport all their wastewater to a WWTP body where it is treated and discharged to a water

Combined Sewers – design aspects

- Because the wastewater is not treated before it obtained with a minimal flow of 0.6 to 0.75m/s will not allow particles to accumulate), generally maintain self-cleansing velocity (i.e. a flow that is transported, the sewer must be designed to where it is treated and discharged
- A constant downhill gradient must be maintain self-cleansing velocity guaranteed along the length of the sewer to

Combined Sewers – design aspects

- When the required slope cannot be maintained, a pumping station must be installed
- Primary sewers are laid beneath roads, at minimal depths of 1.5 to 3 m to avoid damages caused by traffic loads
- Access manholes are set at regular intervals changes in pipeline direction and at drops along the sewer, at pipe intersections, at

Combined Sewers – health aspects


- provide a high level of hygiene and comfort for the user at the point of use
- the ultimate health and environmental impacts the downstream wastewater treatment facility are determined by the treatment provided by

Combined Sewers – cost consideration

- ▶ The initial cost is high (50 to 80% more than simplified sewer systems)
- Maintenance costs are high compared to inspection, unblocking and repair decentralised systems and consists mainly
- Extension of the system can be difficult and costly

Combined Sewers – Operation and /laintenance

- Manholes are installed wherever there is a change of gradient or alignment
- Maintenance require trained professionals




Combined Sewers – Applicability

- Suitable for urban areas with resources to implement, operate and maintain the system
- Appropriate when a centralised treatment facility is available
- Planning, construction, operation and maintenance require expert knowledge
- Infiltration may hamper the performance combined sewers

Combined Sewers

Advantages	
Convenience (minimal intervention by users)	High capital costs
Low health risk	Need a reliable supply of piped water
No nuisance from smells, mosquitoes or flies	Difficult to construct in high-density areas, difficult and costly to maintain
Stormwater and wastewater can be	<u>e</u>
וומוומצבע מר רווב אמוווב רווווב	becomes difficult
No problems related to discharging	Unsuitability for self-help, requires
industrial wastewater	skilled engineers and operators
Moderate operation and maintenance	Problems associated with blockages and
costs	breakdown of pumping equipment
	Adequate treatment and/or disposal
	required

Combined Sewer System Separate



- Separate sewer systems are designed to convey wastewater and stormwater in separate pipes
- Sanitary sewer systems collect and transport wastewater
- Storm sewer systems collect and transport stormwater runoff
- Sanitary sewer systems may also collect wet defects in the pipes and manholes drains or storm sewers, as well as through weather flow via illicit connections from house

separate Sewers – cost and health spects

- The construction costs can be higher than for separated networks are necessary the combined sewer system because two
- they provides a high level of hygiene and comfort
- in a properly constructed separated system the overflow into the environment directly to the treatment plant and cannot sewage is transported in a closed system

Separate Sewers – Applicability

- The same applicability as combined sewer
- Suitable for urban areas with resources to implement, operate and maintain the system
- Appropriate when a centralised treatment facility is available
- Especially suitable in areas where irregular, combined sewer overflows heavy rainfall is expected to avoid frequent


Separate Sewers

Advantages	
Surface run-off, greywater and blackwater can be managed separately	Needs a reliable supply of piped water
Limited or no risk of sewage overflow	Difficult to construct in high-density areas, difficult and costly to maintain
Convenience (minimal intervention by users)	High capital costs, more expensive than
Low health risk	Requires skilled engineers and operators
No nuisance from smells, mosquitoes or flies	Need for pumping on flat ground
No problems related to discharging industrial wastewater	Problems associated with blockages and breakdown of pumping equipment
Moderate operation costs	Adequate treatment and/or disposal required for a large point source discharge
Surface run-off and rainwater can be reused	
(e.g. for landscaping or agriculture)	

Separate Sewers

Combined Sewer System

Separate Sewer System



Overview

Wastewater Residential

*N*astewater

Fresh Water **Facilities**

> the sewer system. can cause an overflow to


Simplified and Condominal Sewers

- describe a sewer system that is constructed conventional sewers depth and at a flatter gradient than using smaller diameter pipes laid at a shallower
- Allows for a more flexible design associated connected households with lower costs and a higher number of
- Because the sewers are more communal, they are often referred to as condominal sewers

implified sewer – basic design principles

- They operate as conventional sewers but with a number of modifications:
- the minimum diameter and the minimum cover are reduced
- Expensive manholes are replaced with simple inspection chambers or flushing points per dealer seems of the chambers or flushing points per dealer seems of the chambers of the chambe
- Sewers are laid within the property boundaries and side walks, rather than beneath the central road
- the slope is determined by using the tractive force concept rather than the minimum velocity concept,
- Sewers should be designed to take into account the extra flow that may result from stormwater infiltration

Because simplified sewers are laid on or around rates can be achieved, fewer and shorter pipes the property of the users, higher connection the pipes will not be subjected to heavy traffic can be used and less excavation is required as



Simplified vs conventional sewers pipe layout

Simplified sewer – cost consideration

- The costs of simplified sewerage systems are even lower than those of onsite sanitation conventional gravity sewerage), sometimes low (50 to 80 % less expensive than
- This is because simplified sewerage uses flatter diameter pipe and simple inspection units gradient, shallow excavation depths, small

/laintenance Simplified sewer – Operation and

- Blockages need to be removed and the system needs to be flushed periodically
- The pipeline system components, such as regularly checked and maintained cleanouts or ventilation points should be

23

Simplified sewer – Applicability

- Where the ground is rocky or the groundwater table is high
- They can be installed in almost all types of dense urban settlements settlements and are especially appropriate for
- It is recommended that the scum from greywater, heavy solids and garbage be the sewer to avoid frequent clogging removed from the wastewater prior to entering


simplified sewer

Advantages	
Can be built and repaired with locally available materials	Requires enough water for flushing
Capital costs are between 50 and 80 % less	Requires expert design and construction
than conventional gravity sewers	supervision
Operating costs are low	Requires frequent repairs and removals of blockages
Can be extended as a community changes	only suitable where there are interceptor
and grows	tanks, septic tanks or other on-site pre-
	treatment systems

- These are similar to conventional sewer system systems, except that the wastewater is presettled and solids removed before entering the
- As solids are removed, sewer diameter can be resulting in significantly lower investment costs gradients, fewer pumps, less pipe depth, etc.) using less conservative design criteria (lower much smaller and they can be constructed
- Due to the simplified design, solids-free sewers can be built cheaper

solids-free Sewers - design aspects

- A precondition is an efficient pre-treatment at bibes smaller and they can be constructed settleable particles that may clog the small the household level. The interceptors remove
- If well used and maintained,
- there is little risk of clogging; hence, the sewers do not have to be self-cleansing and can be laid at shallow depths,
- can have fewer inspection points (manholes),
- gradients (i.e. negative slope) can follow the topography more closely and can even have inflective



laintenance iolids-free Sewers – Operation and

- performance The pre-settling units must be maintained and emptied regularly to ensure optimal
- The risk of pipe clogging is low if the sewers are maintenance is required periodically well operated and maintained, however, some
- Regardless of performance, the sewers should be flushed once a year

solids-free sewer – Applicability

- They are well suited for areas where soak pits or lack of space for on-site infiltration are inappropriate due to sensitive groundwater
- discharge of non-pre-settled wastewater into the sewers should be prevented
- require a constant supply of water, although sewers less water is needed compared to conventional

solids-free sewer


Advantages	
Can be built and repaired with locally	Requires repairs and removals of
available materials	blockages more frequently than a
	conventional sewer
Low operating costs if well maintained	Requires expert design and construction
	supervision
Can be extended as a community	Requires education and acceptance to be
changes and grows	used correctly
Appropriate for densely populated areas	Effluent and sludge (from interceptors)
with sensitive groundwater or no space	requires secondary treatment and/or
for a soak pit or leaching field	appropriate discharge

ressurised Sewers

- Pressurised sewers differ from conventional wastewater pumps instead of gravity to transport gravity collection systems, because they use
- The primary effluent is delivered to the collection tank by gravity where it is grinded pressurised system by pumps (pressed) before being transported into the
- The system can be built with only shallow trenches and relatively small-diameter pipes

ressurised Sewers

It is an effective solution where conventional groundwater table or densely populated areas or areas with a high systems are impractical such as in rocky, hilly




ressurised Sewers - Working Principle

- A pit containing a grinder and pump or holding tank with a pump are installed close to a settling unit (septic tank) connected to a
- When a certain level of effluent has been generating the pressure for transportation collected, it is pumped into the sewer, the user

ressurised Sewers – cost consideration

- High capital costs, but still lower than gravity sewer system
- The cost include the pump, basin, controls, electrical service, and installation



ressurised Sewers – Operation and naintenance

- All system components should be regularly serviced
- Electricity needs to be available all the time
- The pumps should be checked regularly and the pipe connections should be controlled for leakages
- Frequency of operation and maintenance complexity of components used public health and the environment and the depend on wastewater volume, relative risk to

ressurised Sewers – Applicability

- adequate flow (and require pumping) installation at great depths to maintain Flat topography: gravity systems demand
- Rock layers, running sand or a high groundwater table make deep excavation difficult
- Densely populated areas smit ant lie aldslisva ad dit

ressurised Sewers


Advantages	
Effective wastewater transportation at	Needs expert design
minimum depth, minimising excavation for piping system	
Independent from land topography	Needs a permanent energy source for
	the grinder pumps
Less costs compared to a conventional	High capital costs
gravity sewer	
Requires little water only for	Requires skilled engineers operators
transporting the excreta	

acuum Sewers

- Vacuum sewer systems use a central vacuum households to a central collection station source to convey sewage from individual
- Vacuum sewers use differential air pressure (negative pressure) to move the sewage
- A central source of power to operate vacuum pumps is required to maintain vacuum (negative pressure) on the collection system

acuum Sewers – working principle

- A gravity line carries wastewater down to the collection chamber
- As soon as the level reaches a defined height, the vacuum sewer main the vacuum interface valve opens and the negative pressure sucks the wastewater into
- When the collection tank at the end of the sewer system sewage pumps transfer the contents to a treatment plant via a conventional or separate vacuum system fills to a predetermined level,



acuum Sewers - Costs Considerations

- As it is a high-tech system, it is costly, but cheaper than conventional sewer system
- Piping costs are lower (smaller dimensions) and is independent from the topography pipe installation can be cheaper because piping
- deep trenches, No heavy machinery is necessary to excavate
- Big amounts of flushing water can be saved
- The constant energy requirement for the increase the costs permanent vacuum generation, however, can

laintenance acuum Sewers - Operation and

northerenan millingy transfer

- maintenance and operation works person The system needs instructed workers for
- tested from time to time seems to exceed the Pressure in the vacuum sewer system should be
- The risk of clogging is low and there is almost no cleaning/emptying work to do

acuum Sewers - Applicability

Suitable in

- areas where a collection is needed but other options are too costly or not feasible
- Flat topography: gravity systems demand installation at great depths to maintain adequate flow
- areas where rock layers or a high groundwater table make deep excavation difficult
- areas short of water supply necessary for operation of gravity systems
- areas with obstacles to a gravity sewer route

acuum Sewers

Advantages	
Requires less water to transport the excreta	Needs expert design
Considerable savings in construction	Needs energy to create the permanent
costs, and much shorter construction	vacuum
period of the state of the stat	
Pipelines laid in shallow and narrow	High capital costs
trenches, Small diameter pipelines,	
flexible pipeline construction	
Sewers and water mains can be laid in a	Recycling of nutrients and energy
common trench	becomes difficult
Closed systems with no leakage or	Unsuitability for self-help, requires
smell	skilled engineers operators
No manholes along the vacuum sewers	

Dpen Channels and Drains

- An open channel is a conveyance in which water flows with a free surface
- Although closed conduits such as culverts and natural and improved watercourses, gutters, partially full, the term is generally applied to storm drains are open channels when flowing ditches, and channels

principle)pen Channels and Drains – design


- An open channel or drain system generally network of small drains attached consists of a secondary drainage system, with a
- These small drains bring the water to a primary large areas (also called interceptor drains), which serve drainage system, composed of main drains
- The main drains are generally connected with natural drainage channels such as rivers or

streams

)pen Channels and Drains – design principle


- On steep terrain, erosion could damage the drain and flow retarding structures may be necessary
- In flat low-lying areas the limited slope may results in channel with a composite

Den Channels and Drains



Flood flow

etard flow in steep terrains affles, steps and check walls to



Den Channels and Drains - Cost Considerations

- Less expensive compared to underground sewer systems
- The cost depends on local conditions
- velocity and • in very step terrain - extra construction to slow down the flow
- in very flat areas or high groundwater table wide excavation could raise the cost

Den Channels and Drains - Applicability

- Can be constructed in almost all types of settlements (urban or rural), but enough land constructions or high groundwater table - wide area is required to build a reasonable
- Even though they offer simple solutions for public health and the environment due to the waste xpansive compared to underground sawe stormwater drainage, they bear many risks for risk of illegal discharge of wastewater and solid

Den Channels and Drains

Advantages	
Less expensive	High health risk due to illegal discharge
	of wastewaters and solid waste
Simple to construct	Breeding ground for insects and pests
Construction materials are often locally	Regular cleaning service required to
available	remove solids and blockages which
	usually causes spill-over and flooding

- Walski, T. M., and T. E. Barnard (2004), design, Haestad Press. Wastewater collection system modeling and
- http://www.sswm.info
- http://www.cleanwateratlanta.org